


WASTE OIL BURNER PARTS

(PLAN VIEW)

56920 SLEEVE S/W ASM
57235 QUICK CONNECT ELL
57240 QUICK CORD NOT SHOWN
56913 METAL AIR BOX
100333 METAL BOX (500 BURNER)
57110 SET OF ELECTRODES
81974 INLET AIR VENTURI

10785040 BRAIDED SLEV.
39552 1/4 THUMBSCREW
57144 GAUGE VAC/PR.
57207 SAFETY CONTROL
57157 FILTER: FOR 57156
57143 BOWL: FOR 57156
57156 AIR REGULATOR
57140 INCL: 57156,57144



32321 FLANGE SQUARE
57116 RETENTION HEAD
10558530 PLUG/CAP
57205 AIR TUBE W/ HOLE
57189 BURNER CASTING
57204 BLOWER WHEEL


57209 CAD CELL W/LEADS
57222 IGNITER W/ BUSS BARS
56989 BUSS BAR (TWO REQD
FOR 57222)
56377 BAND W/ SLOTS

57280 GROMMET

56921 UPPER CLAMP PLATE FOR ELECTRODES, LOCATED UNDER 10558530 PLUG
56998 CARTON FOR BURNER W/ PRE FORMED FOAM HALVES

BURNER ITEMS (LEFT SIDE)

57130 OIL REG' W/ GAUGE
57129 OIL REG' W/O GAUGE
13100320 PLASTIC PLUG
57144 GAUGE
101050 THUMB SCREW
10820111 MODEL LABEL
10850020 LABEL: INDICATOR



52321 PLATE W/ SLOTS
56974 PLATE W/O SLOTS
100562 PLATE W/ SLOTS
57174 AIR LINE W/ NUTS/FERRULES
56906 METAL OIL BOX
56377 BAND W/SLOTS
GREEN 57122
LIGHT: RED 57120, AMBER 57121
10850270 LABEL "HOT WHEN.."

OIL REGULATOR EXPLODED VIEWS ARE IN MANUAL

BURNER ITEMS (RIGHT SIDE)

10850240 LABEL PATENT

10860450 LABEL (PRIME)

10850040 LABEL CLEAN AIR

10863950 LABEL: METAL

57169 TOGGLE SWITCH

57197 SELF DRILL SCREW
(12 PER BURNER)



10050950 ELL: 1/4 F X 1/8 F

56932 BRACKET

13100320 PLUG PLASTIC

57200 MOTOR 1/7 HP

57203 MOTOR 1/5 HP (AIR PUMP BURNER)

57185 SOLENOID W/ ORIFICE (USED ONLY ON 2-STAGE MODEL 500 BURNERS)
APPEARANCE IS LIKE A 57190 ON OUTSIDE

PREHEAT BLOCK ITEMS

NOZZLE & BLOCK EXPLODED VIEWS ARE IN MANUAL

57103 NOZZLE: MODEL 155 & LOWER

57107 NOZZLE: MODEL 175

57105 NOZZLE: MODEL 200 TO 315

57106 NOZZLE: MODEL 350


57108 NOZZLE: MODEL 500

ALL COME W/ ORING

57186 O-RING FOR NOZZLE

57177 PLATE: RETAINING W/ SCREWS

57181 SCREW: FOR 57177 (4 REQD)



57175 BLOCK: ALUM (INCL. 101084 PLUGS)

101084 BLOCK PLUG: 1/8 MPT, STEEL, SQ. SOCKET

101261 BIT: SQ., FOR REMOVING 101084

57179 NOZZLE ADAPTER W/ ORING *

* 57182 O-RING: LARGE, FOR ADAPTER


* 57184 O-RING: SMALL, FOR ADAPTER

SLIDER GUN ITEMS

30080900 SCREW (2 REQD)
57172 MALE ISO PLUG

57196 NIPPLE


57198 BUSHING: BRASS



30060450 SCREW (3 REQD)

57206 MPT X 1/4 COMP
57285 BUSHING: 7/8 PLASTIC

OIL BOX ITEMS



57118 6 POLE STRIP
57160 130 WATT HTR
*57211 ELL
57190 SOLENOID
10555500 WIRE TIE
10566160 JUMPER CLIP
57197 SELF DRILL SCREW
57198 BUSHING


*11166 FERRULE 1/4
*11168 NUT 1/4
57195 COPPER TUBE FORMED
57165 300 WATT HTR
57149 160 SENSOR
57146 140 SENSOR
* 57211 ELL

* 57206 ELL ASM: INCLUDES 57211, 11166, 11168

11191 ELL: 1/8 MPT X 1/8 MPT (NOT VISIBLE BUT USED AT INLET TO SOLENOID)

SOLENOID EXPLODED VIEWS ARE IN MANUAL

AIR BOX ITEMS




SOLENOID EXPLODED VIEWS ARE IN MANUAL

AIR BOX ITEMS

57198 BUSHING 1/4 X 1/8

13403360 NIPPLE 1.5" INTO AIR SOL.

13403560 NIPPLE 5" OUT FROM AIR TANK



57173 ISO 3-POLE ELECTRICAL PLUG

56967 AIR TANK

42209200 TIMER USED IN 500 BURNERS

BLACK FINISHED STEEL AIR BOXES

56913 STEEL AIR BOX

111830 STEEL AIR BOX FOR AIR PUMP BURNERS


100333 STEEL AIR BOX, LARGE USED W/ TIMERS

AIR PUMP COMPONENTS

57217 FTG: 1/8 FPT X 1/4 COMP

111826 VALVE
11236 AIR FILTER
11237 1/4 M x BARB

57180 AIR SWITCH
57206 FTG: 1/8 M X 1/4 COMP
57144 GAUGE



15041700 1/4 HEX SCREW (2 REQ)
32340 SHAFT COUPLER FOR AIR PUMP

111235 AIR PUMP *
10053451 CROSS: BRASS 1/8 &
13403370 NIPPLE 1/8 X 2

57198 BUSHING 1/4 X 1/8

10053452 1/8 TEE BRASS FPT
57144 GAUGE

* 11233 AIR PUMP REPAIR VANE
* 11234 AIR PUMP REPAIR GASKET
*11238 REPAIR KIT (4 VANES,
1 EACH WEAR PLATE & GASKET)

USED WITH COPPER OR ALUM. 1/4 TUBE:
57206 ELL ASM: INCLUDES 57211, 11166, 11168
11166 FERRULE 1/4
11168 NUT 1/4
57211 FTG: 1/8 MPT X 1/4 COMP

9/64 VENT HOLE IN PLUG